



TABLE OF CONTENTS

4.	MAI	NTENANCE AND REPAIRS	12			
	3.1	Restoring Normal Operation	12			
3.	MAM	NUAL OPERATION	11			
	2.5	Mechanical Stops	10			
	2.4	Wiring The Operator	10			
	2.3	Installing The Operator	8			
	2.2	Installation Dimensions	7			
	2.1	Preliminary Checks	7			
2.	INST	ALLATION	7			
	1.3	Electrical Setup	7			
	1.2	Technical Specifications	7			
	1.1	Dimensions	6			
1.	DES	CRIPTION AND SPECIFICATIONS	6			
	\$418 C	PPERATOR				
	Installin	g the Warning Signs	5			
	UL325 (Gate Operator Classifications	5			
	General Safety Precautions					
	Important Installation Information					
	Important Safety Information 3					

E024U CONTROL BOARD

1. Description and Characteristics	13
2. Inputs / Outputs Description	14
3. Safety Devices Connections	15
4. Programming	17
5. Led Diagnostics	20
6. Time Learning (Set-Up)	22
7. Obstacle Detection	23
8. Enclosure	23
9. Power Connection	24
10. Backup Battery	25
11. Firmware Upgrade	25
12. Function Logics	26
13. Accessories	29

SPARE PARTS

Spare Parts Diagram	32
opaic rans blagiann	C C





IMPORTANT SAFETY INFORMATION

WARNING - to reduce the risk of severe injury or death:

- 1. READ AND FOLLOW ALL INSTRUCTIONS.
- 2. Never let children operate or play with the gate controls. Keep remote controls away from children.
- 3. Always keep people and objects away from the gate. NO ONE SHOULD CROSS THE PATH OF A MOVING GATE.
- 4. Test the gate operator monthly. The gate MUST reverse on contact with a rigid object or stop when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of injury or death.
- 5. Use the emergency release only when the gate is not moving.
- 6. KEEP GATES PROPERLY MAINTAINED. Read the user's manual. Have a qualified service person make repairs to gate hardware.
- 7. The entrance is for vehicles only. Pedestrians must use a separate entrance.
- 8. SAVE THESE INSTRUCTIONS.

IMPORTANT INSTALLATION INFORMATION

- a) Install the gate operator only when:
 - 1) The operator is appropriate for the construction of the gate and usage Class of the gate,
 - 2) All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 1.83 m (6 ft) above the ground to prevent a 57.2 mm (2-1/4 in) diameter sphere from passing through openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position,
 - 3) All areas of the moving vertical pivot gate panel from the bottom of the gate to the top of the gate or a minimum of 1.83 m (72 in) above grade, whichever is less, that pass by a fixed stationary object, and in the area of the adjacent fence that the gate covers during the travel of the gate, shall be designed, guarded or screened to prevent a 57.2 mm (2-1/4 in) diameter sphere from passing through such areas.
 - 4) All exposed pinch points are eliminated or guarded, and

- 5) Guarding is supplied for exposed rollers.
- 6) The operator instructions shall list the maximum number of open and close entrapment protection devices capable of being connected to the operator.
- b) The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
- c) The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
- d) The gate must be properly installed and work freely in both directions prior to the installation of the gate operator. Do not over-tighten the operator clutch or pressure relief valve to compensate for an improperly installed, improperly functioning, or damaged gate.
- e) For gate operators utilizing Type D protection:
 - The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving,
 - 2) An additional placard that is marked in letters at least 6.4-mm (1/4-in) high with the word "WARNING" and the following statement or the equivalent: "Moving Gate Has the Potential of Inflicting Injury or Death – Do Not Start Gate Unless Path is Clear." shall be placed adjacent to the controls,
 - An automatic closing device (such as a timer, loop sensor, or similar device) shall not be employed, and
 - 4) No other activation device shall be connected.
- f) Permanently mounted controls intended for user activation must be located at least 1.83 m (6 ft) away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls.

Exception: Emergency access controls only accessible by authorized personnel (e.g. fire, police, EMS) may be placed at any location in the line-of-sight of the gate.

- g) The Stop and/or Reset buttons must be located within lineof-sight of the gate. Activation of the reset control shall not cause the operator to start.
- h) A minimum of two (2) WARNING SIGNS shall be installed, in the area of the gate. Each placard is to be visible by persons located on the side of the gate on which the placard is installed.
- i) For gate operators that utilize a non-contact sensor (photo beam or similar):
 - 1) See instructions on the placement of non-contact sensors for each type of application,
 - Care should be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving, and
 - One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.



- j) For gate operators that utilize a contact sensor (edge sensor or similar):
 - One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge, trailing edge, and postmounted both inside and outside of a vehicular horizontal slide gate.
 - 2) One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
 - 3) One or more contact sensors shall be located at the pinch point of a vehicular vertical pivot gate.
 - A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.
 - 5) A wireless device such as one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless device shall function under the intended end-use conditions.
 - 6) One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 152 mm (6 in) but less than 406 mm (16 in) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
 - 7) One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).

GENERAL SAFETY PRECAUTIONS

Gate Construction

Vehicular gates should be constructed and installed in accordance with ASTM F2200: Standard Specification for Automated Vehicular Gate Construction.

For a copy of the standard, contact ASTM directly at 610-832-9585 or www.astm.org

Installation

- If you have any questions or concerns regarding the safety of the gate operating system, do not install the operator and consult the manufacturer.
- The condition of the gate structure itself directly affects the reliability and safety of the gate operator.
- Only qualified personnel should install this equipment. Failure to meet this requirement could cause severe injury and/or death.
- The installer must provide a main power switch that meets all applicable safety regulations.
- It is extremely unsafe to compensate for a damaged gate by increasing he operator's force.
- Install devices such as reversing edges and photo beams to provide better protection for personal property and pedestrians. Install reversing devices that are appropriate to the gate design and application.
- Before applying electrical power, ensure that voltage requirements of the equipment correspond to the supply voltage. Refer to the label on your gate operator system.

Usage

- Use this equipment only in the capacity for which it was designed. Any use other than that stated should be considered improper and therefore dangerous.
- The manufacturer cannot be held responsible for damage caused by improper, erroneous or unreasonable use.
- If a gate system component malfunctions, disconnect the main power before attempting to repair it.
- Do not impede the movement of the gate, you may injure yourself or damage the gate system as a result.
- This equipment may reach high thermal temperatures during normal operation, therefore use caution when touching the external housing of the gate operator.
- Use the manual release mechanism according to the procedures presented in this manual.
- Before performing any cleaning or maintenance operations, disconnect power to the equipment.
- All cleaning, maintenance or repair work must performed by qualified personnel.



UL325 Gate Operator Classifications

CLASS I - RESIDENTIAL VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in garages or parking areas associated with a residence of one to four single families.

CLASS II - COMMERCIAL / GENERAL ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in commercial locations or buildings such as multi-family housing units (five or more single family units), hotel, garages, retail store, or other buildings accesible by or servicing the general public.

CLASS III - INDUSTRIAL / LIMITED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not accessible by or intended to service the general public.

CLASS IV - RESTRICTED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in guarded industrial locations or buildings such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

Installing the Warning Signs

This FAAC swing gate operator is supplied with two warning signs to alert people that a possible hazard exists and that appropriate actions should be taken to avoid the hazard or to reduce exposure to it.

Permanently install one warning sign on each side of the gate so they are fully visible to traffic and pedestrians.

Use appropriate hardware such as metal screws (not supplied) to permanently install each warning sign.



FAAC

S418 OPERATOR

1. DESCRIPTION AND SPECIFICATION

The FAAC 418 is an automatic gate operator for swinging gate leafs. It is designed for residential applications and its versatility can accommodate different combinations of gate weights and lengths. The self-contained \$418 operator consists of an electric motor that drives a worm screw housed in an aluminum casing, with built in positive stops.

The non reversable mechanism guarantees the mechanical locking of the leaf when the motor is not operating. An easy-to-use release device allows to move the leaf in case of malfunction or a power outage. The rear bracket is adjustable to gurantee maximum flexifility during the installation phase.

The \$418 Operator is designed and manufactured to automate vehicular swing leaf gates. Do not use for any other purpose.



1.1 Dimensions





1.2 Technical Specifications

Power Supply	24 Vdc
Nominal Power	35 W
Absorbed Current	1.5 A
Maximum Thrust Force	404 lbf (180 daN)
Stroke	13.8 in (350 mm) *
Cycles per day at 68 °F (approx)	80
Class of operation	Residential
Rod speed	0.7 in/sec (1.8 cm/sec)
Ambient Operating Temperature	4°F +131°F (-20 °C +55°C)
Operator Weight	13.2 lb (6 Kg)
Protection Class	IP54

^{*} If the mechanical stops on opening and closing are not used the operator stroke increases to 15.3 in (390 mm)

Gate Length	Gate Weight
10 ft (3.0 m)	up to 720 lb (326 Kg)
12 ft (3.7 m)	up to 500 lb (227 Kg)
14 ft (4.3 m)	up to 370 lb (168 Kg)
16 ft (4.9 m)	up to 280 lb (127 Kg)

1.3 Electrical Setup



Part	Description	Cables
_		2 x AWG 14 (max 30')
1	Operators	AWG 12 (max 50')
		AWG 10 (max 100')
2	Control Unit	3 x AWG 14 (AC Power)
3	TX Photocells	4 x AWG 20
4	RX Photocells	2 x AWG 20
5	Key Switch	2 x AWG 20 (1 contact)

The installer is responsible for providing the main power breaker switch, and for making sure that the entire gate system meets all applicable local electrical codes.

Make sure to locate all controls that operate the gate system at least 6 ft away from any moving parts.

2. INSTALLATION

2.1 Preliminary Checks

The structure of the gate directly influences the reliability and safety of the automated system. To ensure correct operation, the structure of the gate must have the following characteristics:

- The length of leaf must conform to what is shown in the technical specifications.
- The structure of the leaves must be sturdy and rigid, suitable for an automated system.
- There must be regular and uniform movement of the leaves, with no friction or sticking along their entire movement.
- Hinges must be solid and in good condition.
- Gate must swing level.

2.2 Installation Dimensions

Select the assembly position of the operator on the gate, referring to Figure 4 and the relative table. Choose whether or not to use the built in mechanical positive stops; eliminating the mechanical stops increases the working stroke of the operator and values \bf{A} and \bf{B} must be changed.



	α	А	В	C 1	D 2	Z 3	L	Е ³
	٥٥°	6½	6½	13	31⁄2	3	27	41⁄8
With both stops	90	61⁄8	61⁄8	13¾	31⁄2	31⁄8	27	41⁄8
	110°	6	6	13¾	31⁄8	23⁄4	27	41⁄8
	90°	61⁄8	6½	13¾	4	3	28	41⁄8
With open stop		7	7	141⁄8	4	31⁄8	28	41⁄8
	110°	6¼	6¼	141⁄8	31⁄2	23⁄4	28	41⁄8
\\/ith no stores	90°	7	7	141⁄8	4	23⁄4	28	41⁄8
with no stops	110°	65⁄8	65⁄8	15	4	2 ³ /4	28	41⁄8
1		-		·	Din	hensic	ns in	Inches

¹ Working stroke of the operator.

² Maximum value.

³ Minimum value.





If pillar dimensions or hinge position do not allow the installation of the operator, cut a niche into the pillar (as shown in Fig. 6) in order to maintain the proper A dimension. The dimensions of the niche should enable easy installation, rotation and operation of the manual release device.



The rear bracket can be assembled in different configurations to give an array of options to acheive the proper values of the dimensions \bf{A} and \bf{B} .

Fig. 7 shows some of different assembly options of the bracket; all the intermediate positions can also be obtained.

The configuration chosen must permit the assembly of the bracket using both securing bolts.



2.2.1 General Rules for Determining Installation Values

- To obtain opening of the leaf to 90°: A+B=C.
- To obtain opening of the leaf more than 90°: A+B<C.
- Lower A and B values produce higher peripheral leaf speeds.
- Limit the difference between value A and value B to within 1½ inches, greater differences may cause variations in speed during opening and closing gate movements.
- Maintain a Z value that keeps the operator from hitting the pillar.
- The mechanical stops intervene during the first and final 11/2 inches of the stroke. Not utilizing the entire operator stroke could limit the possible adjustments or reduce them to zero.

2.3 Installing The Operator

To correctly install the operator, follow the procedure below:

 Secure the fixed part of the rear bracket in the position determined previously, using a suitable assembly method depending on the material of the pillar. In case of steel pillars the bracket may be welded directly to the them, see Figures 8 and 9.

IMPORTANT: make sure that the bracket is perfectly horizontal using a level.





FAV



2. Install the rear bracket as shown in Figure 10, so as to follow the A and B values determined previously.



3. Secure the rear fork of the operator as indicated in Fig. 11.



4. Bring the moving part of the operator in the position indicated in Fig. 12 (if the mechanical stop at closing is used) or in Fig. 13 (if no mechanical stop at closing is used). The operator could be temporarily powered with a 12Vdc battery to accomplish this.





5. Secure the front bracket to the operator as indicated in Fig. 14.







6. Secure the operator to the rear bracket using the supplied bolt, as indicated in Fig. 15.



- 7. Move the gate leaf to the closed position.
- 8. Bring the operator, together with the front bracket, alongside the leaf.
- Check that the operator is horizontal using a level on the bottom side of the operator as indicated in Fig. 16, and temporarily secure the front bracket with clamps or two welding spots.



NOTE: The axis of the holes of the front bracket must be aligned with the axis of the holes of the rear bracket, as shown in Fig. 17.

> If the structure of the gate does not allow reliable mounting of the front bracket it must be reinforced with plates or similar.



10. Disengage the operator's manual release (see Par. 3) and move the leaf manually, checking that it completes the entire swing, stopping at the mechanical stops.

If during this test the operator hits the leaf of the gate, the value **E** may be increased, (see Fig. 4), up to a maximum of 41/2 inches, using appropriate spacers placed between the front bracket and the gate's leaf.

- 11. Make all the necessary corrections and repeat the procedures from step 9 if needed.
- 12. Permanently secure the front bracket, using a suitable system as indicated in Fig. 18.

if the front bracket will be welded directly to the leaf, the operator must be temporarily removed. Wait for the bracket to cool before reattaching the operator.



2.4 Wiring The Operator

The operator is supplied with the cable already connected. If the cable has to be replaced, use a UL rated cable for outdoor use.

2.5 Mechanical Stops

The S418 operator is supplied with mechanical stops on opening and closing as standard. These may be used in place of mechanical stop-points for the leaf. For adjustment of the stops, proceed as follows:

2.5.1 Opening Stop

- 1. Disengage the operator's manual release (see Par. 4).
- 2. Manually move the leaf into its opening position.
- 3. Loosen the bolt, Fig. 19 ref. 1. The bolt does not need to be completely removed.







4. Move the mechanical stop until it is close to the back side of the bracket, as indicated in Fig. 20.



5. Tighten the bolt.

The mechanical stop is coupled to a toothed section on the operator's body, Fig. 19 Ref. 2. In case of difficulties moving the stop check that the coupling is free. **Do not force it.**

2.5.2 Closing Stop

- 1. Disengage the operator's manual release (see Par. 3)
- 2. Manually move the leaf into its closing position.
- 3. Loosen the bolt, Fig. 21 ref. 1. The bolt does not need to be completely removed.



- 4. Move the mechanical stop until it is close to the front side of the bracket, as indicated in Fig. 22.
- 5. Tighten the bolt.

The mechanical stop is coupled to a toothed section on the operator's body, Fig. 21 Ref. 2. In case of difficulties moving the stop check that the coupling is free. **Do not force it.**



3. MANUAL OPERATION

If the gate system needs to be moved manually due to power outage or an operator malfunction, proceed as follows:

- 1. Turn power off at the main breaker and disconnect the backup battery if present.
- 2. Slide off the protective cap, Fig. 23 Ref. 1.
- 3. Insert the supplied release key, Fig. 23 Ref. 2, and turn it counter-clockwise until it stops, Fig. 23 Ref. 3. The release position is indicated by an open padlock.
- 4. Move the leaf manually.
- NOTE: To keep the operator in manual mode the release device should be left in its current (unlocked) position and main power should be kept off









3.1 Restoring Normal Operation

To restore normal operation mode, proceed as follows:

- 1. Turn power off at the main breaker and disconnect the backup battery if present.
- 2. Turn the release key clockwise until it stops, Fig. 24 Ref. 1, and remove the key, Fig. 24 Ref. 2. The locking position is indicated by a closed padlock.
- 3. Close the protective cap, Fig. 24 Ref. 3.
- 4. Manually move the leaf until the device engages and the leaf locks.
- 5. Power up the system and perform several open/close operations to check that the automated system works normally.
- NOTE: During the first cycle, the operator might not slow down correctly. Wait for the end of the cycle and then give the opening command once again.

4. MAINTENANCE AND REPAIRS

Periodically check the gate structure and ensure in particular that the hinges are in perfect working condition.

Check that the electronic force setting on the control board is adjusted correctly and that the manual release mechanism is fully functional.

Safety devices installed on the system must be checked every six months.

Repairs

For repairs, refer to FAAC authorized service centers.

E024U CONTROL BOARD

1. DESCRIPTION & CHARACTERISTICS



TECHNICAL SPECIFICATIONS

Main power supply	115 V~ 50/60 Hz
Secondary power	24 Vdc - 16 A max.
supply	(min. 20 Vdc max. 36 Vdc.)
Power consumption	stand-by = $1.5W$ max. = $400W$
Max load per motor	7 A
Accessory power	24 Vdc - 500 mA max
Battery charge current	150 mA
Operating temperature	-4 °F +131 °F (-20 °C +55 °C)
Protection fuses	All self-resetting
Main power fuse	6.3 A Timed
Operating Logics	e, a, s, ep, ap, sp, b, c
Operating time out	10 min.
Pause time	Programmable (0 to 4 min)
Motor force, speed, ob-	Programmable with
stacie sensitivity, ciosing delay	dedicated trimmer
Connector inputs	Power supply, Battery,
	Radio receiver, USB
Terminal strip inputs	Encoder, Open A, Open B, Stop, Open safety photocell, Closing safety photocell, Limit switches
Terminal strip outputs	Audio Alarm, Lock, Motors,
	Accessory power supply
Programming	With trimmers, dipswitches
	and pushbutton

RADIO	Connector for the radio receiver
BATTERY	Connector for the backup battery
J24	Jumper to disable battery charging
	(With the jumper present the battery
	charger is enabled)
POWER SUPPLY	DC Power supply input
TR1 to TR6	Programming Trimmers
+24 LED	DC power indicator
SW1 - SETUP	Pushbutton for automatic setup
DS1 - DS2	Programming dipswitches
LED ERROR	Troubleshooting indicator
USB A	USB connection for software upgrade

RADIO CONNECTION

On the radio connector it's possible to plug in receivers RP and RP2. With a single channel radio RP it will be possible to activate only the OPEN A input, with a dual channel radio RP2 it will be possible to activate both OPEN A and OPEN B inputs. Plug in the radio board with the component side towards the internal part of the board.



Make sure you insert or disconnect the board ONLY with the power off.

NOTE: This manual refers to firmware version 1G. The version is shown with the number of flashes of LED USB1 at power up. Version 1G = 5 flashes.



2. INPUTS / OUTPUTS DESCRIPTION



PIN	LABEL	FUNCTION
2 EASY	2 EASY	2easy BUS input for encoders (S800H and S450H only), XIB and loop detector boards
1	OPEN A	N.O. Contact for total opening command
2	OPEN B / CLOSE	OPEN B: N.O. Contact for opening of leaf 1 only (with only one leaf the opening stops at 50% of traveling) CLOSE (LOGIC B-C): N.O. Contact for closing command
3	STOP	N.C. Contact for stop command
4	FSW CL	N.C. Contact for closing safety
5	FSW OP	N.C. Contact for opening safety
6	GND (-)	24 Vdc negative
7	GND (-)	24 Vdc negative
8	+ 24	24 Vdc positive
9	OUT (-)	24 Vdc negative for safety TX photocell (monitored)
10	FCA 1	Open limit switch Motor 1
11	GND (-)	24 Vdc negative
12	FCC 1	Close limit switch Motor 1
13	FCA 2	Open limit switch Motor 2
14	GND (-)	24 Vdc negative
15	FCC2	Close limit switch Motor 2
LAMP	LAMP	Audio Alarm output
LOCK	LOCK	Output for electrical lock, max 5A pulse (DS2 - SW 4=OFF) 12 Vac / 24Vdc Always ON (maglock): max 1 A (DS2 - SW 4=ON) 24 Vdc
MOT1	MOT 1	Motor 1 output (first moving motor)
MOT2	MOT 2	Motor 2 output (second moving motor)
USB A	USB	Firmware upgrade input

3. SAFETY DEVICES CONNECTIONS

Entrapment protection

To comply with the UL325 standard for gate operators every entrapment zone, as defined in ASTMF2200, must be protected by two independent entrapment protection devices. One of the devices is inherent in the E024U control boards design, the other can be external, like a photocell or an edge sensor.

See this picture for the photocells positioning:



Opening Safety Devices:

Are active only during the gate opening movement, and are suitable for protecting the area between the opening leaves and fixed obstacles (walls, etc) against the risk of entrapment

Closing Safety Devices:

Are active only during the gate closing movement, and are suitable for protecting the closing area against the risk of entrapment.

Monitored Devices:

Additionaly the UL325 standard requires that every external entrapment protection device must be monitored for presence and correct operation. To comply with this requirement the E024U control board uses the FAILSAFE function. This function tests the photocells before each movement of the operator. In case the test fails the movement is inhibited. This function is enabled by default on the Closing Safety Input and can be enabled on the Opening Safety Input using dip-switch 12 of DS1 ON.

The power supply negative of the transmitter must be connected to the OUT pin (No.9).

See Fig. A6, A7, A8, A10 for wiring examples.









Only one monitored photocell can be connected to the Closing or Opening safety inputs. More than one photocell or other device can be connected to the safety inputs, but they will not be monitored.

Other devices connected to the safety inputs must have normally closed contacts and wired in series with the main monitored sensor.

See the following example of one closing safety monitored photocell and one non monitored one.



Opening/Closing Safety Devices:

They operate during the gate opening and closing movements and are suitable to protect the opening and closing areas against the risk of impact. Typically these photocells work in combination with other monitored photocell protecting closing or opening entrapment zones. In that case they can't be monitored so they can only protect against potential impact on vehicles.





4. PROGRAMMING

DIP SWITCH DS1 SETTINGS FOR OPERATING LOGIC

OPERATING LOGIC

DS 1: SW 1 - SW 2 - SW 3



LOGIC	SW 1	SW 2	SW 3	PAUSE TIME	DESCRIPTION
E (default) Semiautomatic	OFF	OFF	OFF	NO	One command opens, the next one closes. A command during opening stops the gate
A Automatic	ON	ON	ON	0 - 4 min	One command opens, waits for the pause time an then closes automatically
S Security	OFF	OFF	ON	0-4 min	One command opens, waits for the pause time and then closes automatically. If the closing safety is activated or another command is given during the pause time it closes. A maintained open command will not hold the gate open
EP Semiautomatic step by step	OFF	ON	OFF	NO	One command opens, the next one closes. During the mo- vement a command stops the gate
AP Automatic step by step	OFF	ON	ON	0-4 min	One command opens, waits for the pause time and then closes automatically. A command during the pause time holds the gate open
SP Security step by step	ON	OFF	OFF	0-4 min	One command opens, waits for the pause time and then closes automatically. If the closing safety is activated during pause time the gate closes in 5 s. A command during pau- se time holds open the gate
B Manned Pulsed	ON	OFF	ON	NO	An open A command opens the gate, an open B com- mand closes the gate
C Manned Constant	ON	ON	OFF	NO	Holding open A active opens the gate, holding Open B active closes the gate

For more details on the operating logics please refer to Chapter 11 - Function Logics



ADJUSTING TRIMMERS





DIP SWITCH DS1 SETTINGS FOR BOARD SETUP



FAAC

BOARD SETUP					
DS 1: SW 4 to SW 12					
OPENING DELAY	SW 4	The opening of leaf 2 is delayed after the opening of leaf 1. This is to avo			
0 sec (default)	OFF	ment. In case there is only one leaf it has no effect.			
2 sec	ON				
REVERSE AND LAST STROKE	SW 5	If active, before opening, while the gate is closed, the motors thrust to clo-			
inactive (default)	OFF	are activated for a final stroke after slowdown to facilitate locking of the			
active	ON	electric lock.			
MAX THRUST AT STARTUP	SW 6	With this fuction active the motors work at maximum force at startup (re-			
inactive (default)	OFF	for heavy leaves			
active for 3 sec	ON				
AUTOMATIC OPENING IN CASE OF POWER FAILURE	SW 7	If active and with the optional backup battery installed, the board will open the gate after one minute from the power failure and keep it open. Within the minute wait it's always possible to open and close the acte with			
inactive (default)	OFF	a command. If the logic used has a pause time the board will close the			
active	ON	gare when the power comes back.			
CLOSING SAFETY LOGIC	SW 8	With this function you can choose the behavior of the closing safety. With SW8			
immediate reverse (default) OFF		SW8 ON the gate will stop when the safety is active and it will reverse only whe			
reverse when cleared	ON	the safety is deactivated.			
SHADOW LOOP CONFIGURATION	SW 9	Selects the behavior of the shadow loop function of the Shadow Loop or			
active only on closing (default) OFF		OFF: The shadow loop input is active only before a closing command,			
active on closing and opening	ON	ignored in any other conditions ON: The shadow loop input is active before a closing and before an opening command. If an open command is given and the shadow loop input is engaged the open command will be ignored even after the shadow loop input goes inactive. NOTE: On the first power up of the board an open command will be always executed (even if the shadow loop is engaged), but at reduced speed.			
LOCK OUTPUT CONFIGURATION	SW 10	Selects the behavior of the LOCK output: OFF: The lock output can drive a maglock or a strike lock (see DS2)			
the output drives a regular lock	OFF	ON: The lock output indicates the gate status or drives a warning light (see			
gate status or warning lamp	ON				
24V ACCESSORY VOLTAGE	SW 11	Selects the behavior of the 24V accessory voltage during battery mode: OFF: The accessory voltage and BUS input are turned off in battery			
24V OFF in Battery Mode	OFF	backup mode ON: The accessory voltage and BUS input are always active even in bat-			
24V ON in Battery Mode	ON	tery backup mode			
FAIL SAFE MODE	SW 12	Selects the behavior of the Fail Safe (monitoring) mode:			
Closing Safety	OFF	OFF: Fail Safe is active on the closing safety photocell input (FSW CL) only ON: Fail Safe is active on both closing safety photocell input (FSW CL) and			
Closing and Opening Safety	ON	opening safety photocell input (FSW OP) NOTE: if using the XIB interface the opening safety on it is also monitored. Refers to the XIB manual for further details.			



DIP SWITCH DS2 SETTINGS FOR OPERATOR TYPE AND LOCK MODE

ON 1 2 3 4 5 6 7 8 9 10 11 12 DS2 DS2 DS2 DS2 DS2 DS2 DS2 DS								
					DS 2			
					LOCK OUTPUT MODE			
IMPORTANT					OUTPUT MODE	SW 4		
DS 2				D\$1-10	Active only for 3 sec. after an open impulse (from gate closed)	OFF		
OPERAIOR SEL	ECIIO	N		OFF	Active always except 3 sec. before an opening	ON		
OPERATOR TYPE	SW 1	SW 2	SW 3		Indicates the gate status	- / •		
S450H, S800H	OFF	OFF	OFF	01 10	Active if the gate is Open or in Pause.	OFF		
S418	OFF	OFF	ON	ON	Not active in all other states			
415, 390, 770	ON	OFF	OFF		Warning light output with no pre-flashing. War- ning lamp will be flashing while gate is moving	ON		

5. LED DIAGNOSTICS



L								
E	DESCRIPTION	In BOLD the	In BOLD the normal state with gate closed and working					
D		ON STEADY	OFF	BLINKING				
1	LED BATTERY	Board working on AC power	Board working on battery power or ext supply	Battery charging				
2	LED +24	Main power present	Main power OFF					
			Normal oppration	SLOW BLINK (1 sec. ON - 1 sec. OFF) SET-UP needed				
3	3 LED SEI-UP		Normal operation	FAST BLINK (0.5 sec. ON - 0.5 sec OFF) SET UP in in progress				
4	LED ERROR	Board malfunction. See possible causes below	No errors	Error conditions. See LED ERROR DISPLAY table				
5	LED BUS_MON	Communication on Bus "2easy" OK	Communication bus "2Easy" inactive. Verify encoders for shorts	"2Easy" bus devices with the Same address. Verify encoder LEDs				
6	LED USB2		Software update done or USB key not present	USB key inserted and software Update in progress (DON'T Remove the USB key)				
7	LED USB1		Normal operation	Number of flashes show version at power up: See 10 1				

F/4/



BOARD MALFUNCTION ERROR POSSIBLE CAUSES	SOLUTIONS
There were two consecutive obstacle detections (the audio alarm also should sound)	Remove obstructions
One of the motor driver components has failed	The board needs to be repaired
24V accessory power missing	The board needs to be repaired
The idle current in one of the motors is out of range	Check the motors
Both limit switches are active at the same time	Check the limit switches
Input voltage from the power supply is out of range	Check DC input voltage





The diagnostic LED shows only one error condition at a time, with the priority of the below table. In case there is more than one error once one is eliminated the LED will show the next

	LED ERROR DISPLAY							
NUMBER OF FLASHES	ERROR CONDITION	SOLUTION						
1	OBSTACLE DETECTION	Remove the obstacle, Check force and sensitivity settings						
2	BOARD IN SLEEP MODE (Slow blinking means that the automatic open in case of power failure function is active)	Verify the presence of AC power						
3	Motor 1 Failure	Inspect wiring to motor. If the wiring is good replace motor 1						
4	MOTOR 2 FAILURE	Inspect wiring to motor. If the wiring is good replace motor 2						
5	ENCODER on motor 1 or motor 2 error	 Verify the encoder wiring and LED status. If they are correct replace the encoder Verify motor and encoder wire gauge are correct Verify operator is not on manual and hydraulic units don't need to be bled 						
6	FAIL SAFE FAILED	Verify the photocells wiring and alignement						
7	BOARD THERMAL PROTECTION ACTIVE	Turn off the board and wait until the components cool down						
8	Max run time reached Without finding the Positive stop (10 min.)	 Verify that the operator manual release is not engaged Verify that the board recognizes the mechanical stop, in case redo the setup procedure Verify that the gates slow down before reaching the positive stops. If they don't then redo the setup procedure 						

6. TIME LEARNING (SET-UP)

After powering up the board for the first time or when the board will need it the setup LED will blink at a slow frequency to indicate that the setup procedure to learn the running times is needed.

The setup can be redone at any time by pressing and holding the setup button as indicated below. The setup cannot be done until the safeties and stop inputs are wired.

After the setup first movement, if the leafs are opening instead of closing you need to reverse the wires going to the motor that moves in the wrong direction

AUTOMATIC TIME LEARNING

WARNING: If the time learning setup is done automatically then the slow down points are set by the board on his own

Move the leafs to the mid position Very important for a good result

- Press and hold the SETUP button until the SETUP LED lights up, wait about 3 sec. until it turns off and then release it immediately. NOTE: If you wait too long to release it the manual set-up will start. The LED will blink during the setup procedure
- 2. Leaf 2 (if present) starts to move slowly in closing direction, stopping when it reaches the mechanical stop or FCC2.
- 3. Leaf 1 begins to move slowly in closing direction, stopping when it reaches the mechanical stop, or FCC1.
- 4. Leaf 1 starts to move slowly in opening direction, followed by leaf 2 (if present) still slowly.
- 5. When they both reach the open mechanical stop or FCA1 and FCA2 they stop and reverse, leaf 2 (if present) automatically starts closing at full speed followed by leaf 1.
- 6. When they reach the close mechanical stop or FCC1 and

FCC2 both leafs stop and leaf 1 restarts automatically opening at full speed followed by leaf 2 (if present).

 If you selected an automatic logic the board will wait for the pause time and then closes the gate automatically. Otherwise you have to give an OPEN command to close the gate.

WARNING: If the manual time learning setup is done then the slow down points must be set by the installer during the procedure. **Slow down is required for proper operation.**

Move the leafs to the mid position Very important for a good result

- 1. Press and hold the SETUP button until the SETUP LED lights up, keep it pressed for about 3 sec. until it turns off and keep it pressed more until the leaf 2 (if present) starts moving slowly. The LED will blink during the setup procedure
- 2. Leaf 2 will move in closing direction until it reaches the mechanical stop or FCC2
- 3. Leaf 1 starts moving slowly until it reaches the mechanical stop or FCC1
- 4. Leaf 1 starts moving in opening direction at the set speed (trimmer speed).
- 5. At the point where you want the slowdown to start give an OPEN A command with the push button or the remote that is already stored in memory. Leaf 1 starts to slow down and stops when it reaches the mechanical stop or FCA1.
- 6. Leaf 2 starts moving in opening direction at the set speed (trimmer speed)





- 7. At the point where you want the slowdown to start give an OPEN A command with the push button or the remote that is already stored in memory. Leaf 2 starts to slow down and stops when it reaches the mechanical stop or FCA2.
- 8. Leaf 2 starts to close at the set speed (trimmer speed).
- 9. At the point where you want the slowdown to start give an OPEN A command with the push button or the remote that is already stored in memory. The leaf 2 starts to slow down and stops when it reaches the mechanical stop or FCC2.
- 10. Leaf 1 starts to close at the set speed (trimmer speed).
- 11. At the point where you want the slowdown to start give an OPEN A command with the push button or the remote that is already stored in memory. Leaf 1 starts to slow down and stops when it reaches the mechanical stop or FCC1.
- 12. The manual time learning procedure is complete.

After time learning test the gate to set the force, speed and sensitivity using the trimmers.



- Apply resistance to the gate and adjust the Force to make sure that the operator creates enough thrust to reliably move the leaf.
- 2. Set the desired speed. Keep the speed relatively low on big and heavier gates.
- 3. After Force and Speed are set to the desired settings adjust the Sensitivity so the gate reverses promptly after hitting a rigid object.
- 4. After all the adjustments are done perform setup again.

7. OBSTACLE DETECTION

The obstacle detection function is achieved by controlling the current absorption and / or through the encoder connected to the motors.

If the gate encounters an obstacle during the movement of opening or closing, the obstacle detection function is activated and the operator reverses the direction of the gate.

In case of a second consecutive obstacle the operator stops the gate right away and any further command is inhibited. To re-enable the automation, you must remove power (and disconnect batteries if present) or open the STOP contact input. The Audio Alarm output will be active until this "reset". This is a more detailed description of what happens after an obstacle detection:

Gate opening, obstacle detected:

The gate reverses partially (for 3 sec.) and STOPS. After that the gate is in a halfway position or completely closed.

If an open_A command is received, the gate tries to open from the current position:

- If there is another obstacle detection: the gate stops completely, the alarm goes off
- If the gate reaches the open position: the obstructions count is reset, the gate returns to normal operations

Gate closing, obstacle detected:

The gate reverses partially (for 3 sec.) and STOPS. After that the gate is in a halfway position or completely open.

If an open_A command is received in NON Automatic mode

- if the gate was not completely open: execute an open
- if the gate was completely open: execute a close

If an open_A command is received in Automatic mode:

- if the gate was not completely open: execute an open, wait for the pause time and then closes.
- if the gate was completely open: reload the pausetime, and then closes

If there is another obstacle detection: the gate stops completely, the alarm goes off.

If the gate reaches the close position: the obstructions count is reset, the gate returns to normal operations

8. ENCLOSURE

The E024U board is supplied on a panel that fits in a metal enclosure of this size:





On the back panel there are: the control board, the power supply and additional accessories.



AC POWER CONNECTION

To connect AC power to the controller:

1. Turn the circuit breaker for the AC gate operator power OFF before connecting the AC input wires.

2. Turn OFF the Power Switch located on the right side of enclosure before connecting the AC input wires.

3. Connect the AC input wires to the AC terminal located on the bottom of the control box. See diagram below.

4. Batteries must be connected after the AC power is on. See Battery Power Connection.



9. POWER CONNECTION

AC POWER GUIDELINES:

THE E024U control board and power supply uses a single phase AC power line to operate, charge the batteries, and power gate accessories. Use the following guidelines when installing the AC power:

1. Check the local wiring codes in all cases and follow all local building codes. Wiring and hookup should be performed by a qualified electrician/installer only.

2. AC power should be supplied from a circuit breaker panel and must have its own dedicated circuit breaker. This supply must include a green ground conductor.

3. Use copper conductor wires with liquid tight flexible conduit UL listed for electric cable protection

4. Properly ground the gate operator to minimize or prevent damage from power surges and/or lightning. Use a grounding rod if necessary. A surge suppressor is recommended for additional protection.

POWER SUPPLY

The E024U board is powered by a high efficiency switching power supply that takes 115VAC input and provides 36VDC to power the board. On the power supply board there is only one repleaceble fuse: **6.3A timed**







10. BACKUP BATTERY

The E024U board allows the connection of a 24V backup battery to provide power to operate the gate during blackouts. For more details about how the boards handles the loss of main power and how to configure its behaviour please see par 4.3 and DS1 switch 7.

Two 12V Batteries are located underneath the backplate with the Control Board and Accessories and come prewired from the factory



To enable the Battery Backup connect the Battery cable to the "BATTERY" connector on the control board



Then turn ON the Battery switch on the top right of the enclosure

DISABLE THE BATTERY CHARGER

The internal battery charger must be disabled to use an external charger. To disable the battery charger unplug jumper J24

J24 PRESENT = BATTERY CHARGING ACTIVE J24 NOT PRESENT = BATTERY CHARGING NOT ACTIVE



11. FIRMWARE UPGRADE

The E024U board keeps the operating firmware in a field programmable memory, it can be easily upgraded through the on board USB port



For the upgrade you need a USB Flash Drive, where you have to copy the file supplied by FAAC. Then follow these steps:

- 1. Disconnect the batteries if they are present.
- 2. Turn the AC power off and insert the Flash Drive into the USB A input on the board
- Turn the AC power back on. The USB2 LED will start to flash to confirm the beginning of the software update. (WARNING: DON'T TURN THE POWER OFF OR REMOVE THE FLASH DRIVE UNTIL THE USB2 LED TURNS OFF.
- 4. Wait until the USB 2 LED turns off
- 5. Remove the USB Flash drive.
- 6. Cycle power, reconnect the batteries if needed and execute a new SETUP procedure (See chapter 6)



WARNING: Only upgrade the firmware with the proper file supplied by FAAC, otherwise the board could be damaged

VERIFY THE FIRMWARE VERSION

On initial power up watch the LED USB 1 on the bottom left of the board. The number of flashes indicate the version:

No Flashes	Ver. 1C
1 FLash	Ver. 1D
2 Flashes	Ver. 1E
5 Flashes	Ver. 1G



12. FUNCTION LOGICS

LOGIC "E"		PULSES							
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP			
CLOSED	opens the leaves	opens leaf 1	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)			
OPENING	stops operation (1)	stops operation	stops operation	immediately reverses at closing	no effect	stops and opens at release (OPEN stops - saves CLOSE)			
OPEN	recloses leaves immediately (1)	recloses leaves immediately	no effect (OPEN/CLOSE disabled)	no effect	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)			
CLOSING	reopens leaves immediately	reopens leaves immediately	stops operation	no effect	reverses at opening	stops and opens at release (OPEN stops - saves CLOSE)			
BLOCKED	closes leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN stops - saves CLOSE)			

(1) if the cycle began with OPEN-B (leaf 1), both leaves are activated at opening

LOGIC "A"	PULSES							
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP		
CLOSED	opens and closes after pause time	opens leaf 1 and closes after pause time	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)		
OPENING	no effect (1)	no effect	stops operation	reverses at closing	no effect	stops and opens at release (saves CLOSE)		
OPEN IN PAUSE	reloads pause time (1)	reloads pause time of released leaf	stops operation	no effect	recharges pause time (CLOSE disabled)	recharges pause time (CLOSE disabled)		
CLOSING	reopens leaves immediately	reopens leaves immediately	stops operation	no effect	reverses at opening	stops and opens at release (saves CLOSE)		
BLOCKED	closes leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)		

(1) if the cycle began with OPEN-B (leaf 1), both leaves are activated at opening

LOGIC "S"		PULSES								
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP				
CLOSED	opens and closes after pause time	opens released leaf and closes after pause time	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)				
OPENING	no effect (1)	no effect	stops operation	reverses at closure	continues to open and recloses immediately	stops and opens at release (saves CLOSE)				
OPEN IN PAUSE	recloses leaves immediately (1)	recloses leaves immediately	stops operation	no effect	stops and, at release, closes	stops and, at release, closes				
CLOSING	reopens leaves immediately	reopens leaves immediately	stops operation	no effect	reverses at opening (see DS1-SW8) and closes immediately at end	stops and opens after release and closes immediately at end				
BLOCKED	closes leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)				

(1) if the cycle began with OPEN-B (leaf 1), both leaves are activated at opening



LOGIC "EP"	(1) if the cycle began with OPEN-B (legit Jesboth leaves are activated at opening								
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP			
CLOSED	opens the leaves	opens leaf 1	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)			
OPENING	stops operation (1)	stops operation	stops operation	immediately reverses at closure	no effect	stops and opens at release (OPEN stops - saves CLOSE)			
OPEN	recloses leaves immediately (1)	recloses leaves immediately	no effect (OPEN/CLOSE disabled)	no effect	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)			
CLOSING	stops operation	stops operation	stops operation	no effect	reverses at opening	stops and opens at release (OPEN stops - saves CLOSE)			
BLOCKED	restarts moving in opposite direction. Always closes after STOP	restarts moving in opposite direction. Always closes after STOP	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN stops - saves CLOSE)			

FAA⊂

LOGIC "AP"	PULSES								
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP			
CLOSED	opens and closes after pause time	opens leaf 1 and closes after pause time	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)			
OPENING	stops operation (1)	stops operation	stops operation	reverses at closing (saves OPEN)	no effect	stops and opens at release (OPEN stops - saves CLOSE)			
OPEN IN PAUSE	stops operation (1)	stops operation	stops operation	no effect	recharges pause time (CLOSE disabled)	recharges pause time (CLOSE disabled)			
CLOSING	reopens leaves immediately	reopens leaves immediately	stops operation	no effect	reverses at opening (see DS1-SW8)	stops and opens at release (OPEN stops - saves CLOSE)			
BLOCKED	closes leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)			

(1) if the cycle began with OPEN-B (leaf 1), both leaves are activated at opening

LOGIC "SP"		PULSES								
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP				
CLOSED	opens and clo- ses after pause time	opens leaf 1 and closes after pause time	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)				
OPENING	stops operation (1)	stops operation	stops operation	reverses at closure	continues to open and recloses immediately	stops and opens after release and closes immediately at end (OPEN stops - saves CLOSE)				
OPEN IN PAUSE	recloses leaves immediately (1)	recloses leaves immediately	stops operation	no effect	stops and, at relea- se, closes	stops and, at release, closes				
CLOSING	stops operation	stops operation	stops operation	no effect	reverses at opening	stops and opens at release (saves CLOSE)				
BLOCKED	restarts moving in opposite direction. Always closes after STOP	restarts moving in opposite direction. Always closes after STOP	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)				

(1) if the cycle began with OPEN-B (leaf 1), both leaves are activated at opening





LOGIC "B"	PULSES							
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP		
CLOSED	opens the leaves	no effect	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)		
OPENING	no effect	closes leaves	stops operation	reverses at closure	no effect	stops and, at release, closes (saves OPEN/CLOSE)		
OPEN	no effect	closes leaves	no effect (OPEN/CLOSE disabled)	no effect	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)		
CLOSING	opens the leaves	no effect	stops operation	no effect	reverses at opening	stops and opens at release (saves OPEN/CLOSE)		
BLOCKED	opens the leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)		

LOGIC "C"	CONTINUOS	COMMANDS	PULSES			
SYSTEM STATUS	OPEN A	OPEN B	STOP	FSW OP	FSW CL	FSW CL/OP
CLOSED	opens the leaves	no effect	no effect (OPEN disabled)	no effect (OPEN disabled)	no effect	no effect (OPEN disabled)
OPENING	no effect	closes leaves	stops operation	reverses at closure	no effect	stops and, at release, closes (saves OPEN/CLOSE)
OPEN	no effect	closes leaves	no effect (OPEN/CLOSE disabled)	no effect	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)
CLOSING	opens the leaves	no effect	stops operation	no effect	reverses at opening	stops and opens at release (saves OPEN/CLOSE)
BLOCKED	opens the leaves	closes leaves	no effect (OPEN/CLOSE disabled)	no effect (OPEN disabled)	no effect (CLOSE disabled)	no effect (OPEN/CLOSE disabled)

13. ACCESSORIES

SHADOW LOOP INTERFACE (p/n 790062)

Through the use of the XIB interface board you can connect an additional loop detector (center or shadow) to the E024U board to keep the gate open if vehicles are obstructing the closing path. With a dip switch setting the shadow loop can function on both opening and closing (see section 4.3)



J1 (RED)	Connects to "2easy" BUS input on the E024U
J2 (RED)	Terminal for the connection of the encoder
J3 CL (GREEN)	Terminal for the NC connection of the shadow loop detector
J3 OP (GREEN)	Terminal for the NC connection of second open safety
DL1	LED for diagnostics of devices connected to the J3 OP
DL2	LED for diagnostics of devices connected to the J3 CL

INSTALLING THE INTERFACE

- 1. Turn power OFF
- 2. Plug in the XIB interface to the 2EASY connector on the E024U board
- 3. Wire the shadow loop detector NC output to the CL input on the XIB board as in figure below
- Connect Common from loop detector to GND (terminal 6) on E024U
- 5. If no second open safety device is present jump out the OP input on XIB board to GND (terminal 6) on the E024U
- 6. Wire the encoder (if needed) to J2
- 7. Refer to Fig. A11 for the wiring schematic
- 8. Turn power back ON
- 9. Press and release the SW1 button quickly. The board will recognize that the XIB board has been removed
- 10. Re-program run time if needed.



REMOVING THE INTERFACE

- 1. Turn power OFF
- 2. Unplug the board and remove the wiring
- 3. Move the encoder wires (if present) to the 2EASY connector on the board
- 4. Turn power back ON
- 5. Verify that leaf 1 & 2 lights on the encoder are correct
- 6. Press and release the SW1 button quickly. The board will recognize that the XIB board has been removed
- 7. Re-program run time if needed.

NOTE:

- Do not connect the shadow loop detector in series with regular closing safety devices.
- If the E024U board doesn't have the correct software installed the shadow loop will act as a normal closing safety, detecting also the gate itself and not allowing the closing movement to complete. Please contact technical support for assistance in that case.

SECOND OPEN SAFETY INPUT

The OP input on the XIB board can be used as a second monitored open safety input.

When open safety monitoring is turned ON on the E024U board (Dip SW 12 ON) the OP input on the XIB (J3 OP) is monitored and can be used to protect an entrapment zone. See Fig. A12a/b for the connections.

In case only one opening safey input is needed and the XIB board is present connect the opening safey photocell to FSW OP on the E024U and J3 OP on the XIB in parallel. See Fig. A13a/b for the connections.









DIAGNOSTIC TABLE				
	OFF	SLOW FLASHING (FLASH EVERY 5 secs.)	ON STEADY	FAST FLASHING (FLASH EVERY 0.5 sec)
DL1	"XIB" board malfunction or no power	J3 OP terminal open (missing jumper on the OP input)	J3 OP terminal closed (normal condition)	Error condition on the BUS
DL2	"XIB" board malfunction or no power	J3 CL terminal open (loop detector active or not connected)	J3 CL terminal closed (loop detector in idle condition)	



LOOP DETECTORS INTERFACE (p/n 2670.1)

The Loop Detector Interface allows connection of up to three plug-in detectors associated with standard functions. The board is designed to fit in the FAAC standard 16" x 14" enclosure on the existing DIN rail. To connect the interface board:

1) Connect the 2EASY BUS from the E024U to the interface board (no polarity) - Green Wires

2) Connect pin 8 on the E024U board (+24V) to the +24 input on the interface board - Red Wire

3) Connect pin 7 on the E024U board (GND) to the GND input on the interface board - Black Wire

4) Connect the loops to the interface board as in the figure below

Turn the power on on the E024U board. The LED on the interface board will blink briefly and then will stay ON solid if the BUS connection is working correctly.

IMPORTANT: Briefly press the SW1 button on the E024U board to make it aware of the presence of the additional interface board.

To make sure the board is working properly you can check the behaviour of BUS LED on the E024U board. It will be normally on when none of the loop detectors is active. If any of the detectors is activated the LED will turn off.



NOTE: You can use the shadow loop interface OR the loop detectors interface but not both at the same time. If two monitored open safeties are required the additional loop detectors (other than the shadow) must be wired directly to the E024U board.



SPARE PARTS DIAGRAM



Part	Part Number	Description
1	713002	Triangle Manual Release Key
2	63003356	S418 Complete Release Group
3	63000563	S418 Bodies Group
4	63002565	\$418 Front and Rear Mounting Brackets
5	63003355	\$418 Worm Screw Group
6	63001615	Motor \$418
7	718366	Pin Long w/ C Clip
8	7228015	Rear Fork
9	7182075	Pin Short
10	60202215	Gear and Release Assembly
11	63003354	S418 Small Parts



LIMITED WARRANTY

FAAC International, Inc. ("Seller") warrants the first Purchaser of the product to be free from defects in material and workmanship for a specific period as defined by the Warranty disclosure on the website <u>www.faacusa.com</u>. The Warranty Period commences from the date of invoice.

Control Boards, Accessories or Spare Parts factory installed or sold with any of the products above carry the same warranty period as the product they are sold with, excluding batteries that carry a maximum 2 year warranty.

Products repaired under warranty carry the remainder of the original warranty period. For products repaired outside of warranty, the Seller warrants that all parts used for the repair will be free from defects in materials and workmanship for a period of ninety (90) days.

Defective products must be returned to Seller, freight prepaid by Purchaser, within the warranty period. A Return Material Authorization Number (RMA) must be obtained before product is returned. Items returned will be repaired or replaced, at Seller's option, upon an examination which discloses to the satisfaction of the Seller that the item is defective. The Seller will return the warranted item freight prepaid.

This limited Warranty covers the product under the normal use and service for which it was intended, provided it has been properly installed and operated. Seller's obligations under this warranty shall be limited to the repair or exchange of any part. This warranty shall not apply to products or parts thereof which have been repaired or altered, without Seller's written consent, outside of Sellers's workshop or altered in any way so as, in the judgment of Seller, to affect adversely the stability or reliability of the product(s) or has been subject of misuse, negligence, or accident, or has not been operated in accordance with the product's instructions or has been operated under conditions more severe than, or otherwise exceeding, those set forth in the specifications for such product(s).

When the warranty service involves the exchange of an operator or part, the item the Seller replaces becomes its property and the replacement becomes Purchaser's property. The Purchaser represents that all removed items are genuine and unaltered. The replacement may not be new but will be in good working order and at least functionally equivalent to the item replaced. The replacement assumes the warranty service status of the replaced item.

The products are not warranted to meet the specific requirements, if any, of safety codes of any particular state, municipality, or other jurisdiction, and the Seller doesn't assume any risk or liability whatsoever resulting from the use thereof, whether used singly or in combination with other machines or apparatus.

The Seller does not assume nor authorizes any person to assume for them any other liability in connection with the sale or use of the products of beyond that extended herein.

The warranty hereinabove set forth shall not be deemed to cover maintenance parts, including, but not limited to hydraulic oil, motor brushes, or the like. No agreement to replace or repair shall constitute an admission by the Seller of any legal responsibility to effect such replacement to make such repair, or otherwise. All products sold by the Seller are subject to design and/or appearance modifications, which are production standards at the time of shipment. The Seller may, but shall not be required to, modify or update products shipped prior to a current production standard.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRAN-TIES EXPRESSED OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE. THIS WARRANTY SHALL NOT APPLY TO PRODUCTS OR ANY PART THEREOF WHICH HAVE BEEN SUBJECT TO ACCIDENT, NEGLIGENCE, ALTERATION, ABUSE, OR MISUSE OR IF DAMAGE WAS DUE TO IMPROPER INSTALLATION OR USE OF IMPROPER POWER SOURCE, OR IF DAMAGE WAS CAUSED BY FIRE, FLOOD, LIGHTNING, ELECTRI-CAL POWER SURGE, EXPLOSION, WIND STORM, HAIL, AIRCRAFT OR VEHICLES, VANDALISM, RIOT OR CIVIL COMMOTION, OR ACTS OF GOD.

The Seller shall not be liable for any loss or damage whatsoever resulting, directly or indirectly, from the use or loss of use of the product(s). Without limiting the foregoing, this exclusion from liability embraces a Purchaser's expenses for downtime or for making up downtime, lost profit, damages for which the Purchaser may be liable to other persons, damage to property, and injury to or death of any persons.

This limited warranty extends only to wholesale customers who buy directly through the Seller's normal distribution channels. The Seller does not warrant its products to end consumers. Consumers must inquire from their selling dealer as to the nature and extent of that dealer's warranty, if any.

THE LIMITED WARRANTY OFFERED HEREIN IS THE SOLE AND EXCLUSIVE REMEDY AVAILABLE TO THE PURCHASER. CORREC-TION OF DEFECTS, IN THE MANNER AND FOR THE PERIOD OF TIME DESCRIBED HEREIN, SHALL CONSTITUTE THE COMPLETE FULFILLMENT OF ALL LIABILITIES OF SELLER TO THE PURCHASER WITH RESPECT TO THE COVERED PRODUCT, AND SHALL CON-STITUTE FULL SATISFACTION OF ALL CLAIMS, WHETHER BASED ON CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY LOSS OF PROF-ITS OR ANY INDIRECT, CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES ARISING OUT OF SELLER'S BREACH OF THIS LIMITED WARRANTY, OR ARISING OUT OF THE CUSTOMER'S INABILITY TO USE THE COVERED PRODUCT, EVEN IF SELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to a particular Purchaser. This Limited Warranty gives the Purchaser specific legal rights. The Purchaser may also have other rights, which vary from state to state.

NOTES:	

NOTES:	